



www.vintageair.com

Packing List: 1980-86 Ford F-Series/Bronco without Factory Air Plastics Kit (592984)

No.	Qty.	Part No.	Description
1.	1	592959	Kick Panel Cover
2.	2	592958	Hose Adapter, Driver-Side
3.	1	592952	Defrost Duct, Passenger-Side
4.	1	592953	Defrost Duct, Driver-Side
5.	1	625338	Plenum, Floor
6.	1	652331	Plenum, Defrost
7.	1	625330	Plenum, Dash

Checked By: _____
Packed By: _____
Date: _____

