

### INSTALLATION INSTRUCTIONS 34116VUQ HEATER BULKHEAD

INSTALL THE BULKHEAD PLATE AS FIGURE 1 SHOWS.




FIGURE 1

Make circular ends of opening with 1-1/4" hole saw. Center punch pilot hole with 1-5/8" between centers as shown. When holes are cut; snip remaining bridge for final opening. should match pattern drawn in Figure 2.




FIGURE 2

#### PACKING LIST

NO	QTY	PART NUMBER	DESCRIPTION
1	2	35333VUQ	#10 Bulkhead fittings
2	1	35341VUQ	Bulkhead plate
3	2	35335VUQ	#10 Nuts
4	1	35336VUQ	Bulkhead plate rear bracket
5	1	28215VUB	10-24 x 1/2" Bolt