

WIRING DIAGRAM

- INSTALL THE NEW FAN SWITCH IN ANY UNUSED HOLE IN THE CENTER OF THE DASH.
- THE NEW SWITCH CAN REPLACE THE OEM FAN SWITCH IF IT'S NOT USED TO CONTROL A REAR HEATER.

